



MANUFACTURER AND GLOBAL SUPPLIER OF TEMPERATURE CONTROL SYSTEMS
MOLD CONTROL SYSTEMS, INC.

SITC-15 Temperature Controller GITC-15 Temperature Controller Mainframe Operation Manual



Contents:



SITC Quick Reference:	Pg. 2	Display Codes:	Pg. 11
GITC Quick Reference:	Pg. 3	Mainframe Installation: ..	Pg. 12
Basic Operation Procedures:.	Pg. 4	Cable Pinout:	Pg. 15
SITC Parameters:	Pg. 7	MFCP Mainframe:	Pg. 16
GITC Parameters:	Pg. 8	1-3 Zone Mainframe	Pg. 17



PH: (407)855-2899





FAX: (407)855-2855


www.moldcontrol.com

SITC-15 Quick Reference

Change set-point temp -  or  to desired set-point temp.




Change mode - press  until flashing LED is under desired mode, then 

Change parameters - press  until desired parameter is found. Use  or  to adjust the parameter.  when finished.

Display Amps/Volts - press 







Set-Point Value Display



-  When decimal is lit, manual percentage power is engaged
-  When decimal is lit, voltage is displayed $\pm 3\%$
-  When decimal is lit, temp. is displayed in Celsius



User Input Keypad



-   Up/down keys For adjustment of setpoint/parameters
-  Mode Select key Manual, Auto, Standby, and Boost
-  Amps/Volt key View Current and voltage
-  Parameter key Scroll through parameters
-  Enter key Save changes






Process Value Display



-  When decimal is lit, amperage is displayed
-  When decimal is lit, output power is on

Mode Indicator LEDs



-  SOFT - Soft Start
-  MAN - Manual/Open loop
-  AUTO - Auto/Closed loop
-  STBY - Standby Mode
-  BST - Boost Mode



















Figure 1

GITC-15 Quick Reference

- Global power on/off - press   
- Global setpoint - set desired setpoint, then press   
- Global mode - press   
- Global parameters -   




Set-Point Value Display




-  When decimal is lit, manual percentage power is engaged
-  When decimal is lit, output power is on
-  When decimal is lit, voltage is displayed $\pm 3\%$

Process Value Display



-  When decimal is lit, K type T/C is selected
-  When decimal is lit, amperage is displayed
-  When decimal is lit, temp. is displayed in Celsius

User Input Keypad






-  Global key
See *Global Functions* (Pg. 4)
-  Enter/Start key
Save changes or press once to exit Halt, or twice to start
-  Halt key
Halts the controller (inhibits output)



Figure 2

Basic Operation Procedures

The SITC-15 and GITC-15 temperature controllers are ready to run from factory settings.

Global Functions for GITC only:

GLOBAL FUNCTIONS allow individual controller parameters or modes to be sent to the system or groups of controllers. Group setup is configurable in parameter (**GITC P01**). Up to 4 groups can be set.

GLOBAL POWER ON/OFF: power on or off all controllers from any controller.

Key sequence: *GLBL*, *POWER*, then *ENTER/START*

Note*: If a controller is manually powered off, the function is disabled until powered back on manually.

GLOBAL SETPOINT/PARAMETERS: Adjust setpoint or parameters on a single unit, and send the settings to all controllers.

Key sequence: *GLBL*, *PMTR*, then *ENTER/START*

GLOBAL MODE CHANGE: Change the mode on a single unit, then change mode system wide or within a group. (e.g. STANDBY or BOOST)

Key sequence: *GLBL*, *MODE*, then *ENTER/START*

GLOBAL CURRENT/VOLTAGE VIEW: View current and voltage on all controllers in the system.

Key sequence: *GLBL*, *AMPS/VOLT*, then *ENTER/START*

Note*: If changes need to be made to individual controllers, just apply changes and press *ENTER*.

Basic Operation:

Turn power on by pressing the *POWER* button.

SOFT START mode: The controller will start in SOFT START mode if the process value is below 212° F or 100° C. After the SOFT START duration time (parameter (SITC - P16); (GITC - P20), the controller will go into AUTO mode (factory default).

Note*: MODE changes cannot be made during SOFT START mode unless the lock is disabled in parameter (SITC - P17); (GITC - P21).

SETPOINT CHANGE: To change the setpoint value, use the *UP* and *DOWN* keys to select the desired temperature then press *ENTER*. The minimum and maximum values for temperature and setpoint are 32° - 999° Fahrenheit (5° - 650° Celsius).

Mode:

There are 4 running modes available: manual (open loop), automatic (closed loop), standby (idle), and boost. A solid lit LED indicates the mode the controller is in.

To change mode:

Press the *MODE SELECT* key until the blinking LED is over the desired mode, then press the *ENTER* key. A solid lit LED will indicate the current running mode.

Note*: To exit the mode function with no changes, press the *MODE SELECT* then the *UP* or *DOWN* key.

Siren will momentarily sound when status changes occur (GITC only) (e.g. when BOOST is enabled).

ENTER MUST BE PRESSED AFTER ANY ADJUSTMENT (SUCH AS SETPOINT, PARAMETER, OR MODE) IS MADE TO STORE NEW INFORMATION.

Standby and Boost:

The controller has two configurations for standby and boost modes: auto or manual.

Standby:

AUTO-STANDBY - controller goes to the preset standby set-point temperature set in parameter (SITC - P15); (GITC - P19).

MANUAL-STANDBY - controller goes to the preset % power set in parameter (SITC - P14); (GITC - P18).

The controller will remain in STANDBY mode until it is manually changed to another mode, or by pressing *MODE SELECT* then *UP* or *DOWN*.

Boost:

AUTO-BOOST - controller goes to the preset BOOST set-point temperature set in parameter (SITC - P12); (GITC - P16).

MANUAL-BOOST - controller goes to the preset % power set in parameter (SITC - P13); (GITC - P17).

Controller will remain in BOOST mode until preset time has elapsed, set in parameter (SITC - P11); (GITC - P15).

Parameter Changes:

1. Press the *PMTR* key until the desired parameter is reached. (List of parameters is available on (SITC - Pg. 7) (GITC - Pg. 8).
2. Press the *UP* or *DOWN* key to change the options for the selected parameter.
3. When complete, press the *ENTER* key to store to memory. (Changes can be made to all parameters before pressing *ENTER*).

To exit at any time, press the *ENTER* key.

Error Reset:

Upon detection of TOH, TSH, or HIA, the controller must be powered off, then on, to clear the error once the issue has been corrected. Refer to Pg. 9 for error codes.

Special Functions (GITC ONLY):

Even Temperature Rise: controllers will follow the slowest rising temperature in the system. Even temperature rise is an active procedure, so fluctuation will occur during rise.

Thermocouple Slaving at Startup: At startup, in the event of a thermocouple break, the controller will slave from a controller in the same group.

Live-Swap: In the event of a controller change-out, the new controller will automatically inherit the parameters and settings of the previous controller.

External Alarm Output: Relay for external alarm or light. Pinout on page: 14

Remote Standby Input: Switch input for system standby. Pinout on page: 14

SITC Parameters

#	Parameters	Defaults
P01	Auto Power On - (YES or NO)	YES
P02	Control Type - Power Control Type Phase or Burst mode (PH or BT)	PH
P03	Over Current Limit - (1 - 21) Amps	16
P04	Celsius or Fahrenheit (°C or °F)	F
P05	Thermocouple Type - (J or K)	J
P06	Over-temp. Alarm Limit - (8° - 30° Fahrenheit), (6° - 17° Celsius)	30
P07	Under-temp. Alarm Limit - (5° - 30° Fahrenheit), (5° - 17° Celsius)	30
P08	T/C Pinched - (1 - 250) seconds or (000 = disabled)	60
P09	Open TRIAC, Heater - (1 - 240) seconds or (000 = disabled)	30
P10	APO Enable - (YES or NO)	YES
P11	Boost Time Setting - (5 - 999) seconds	30
P12	Boost Temperature - (5° - 250° Fahrenheit), (5° - 120° Celsius)	75
P13	Manual Boost Power - (5 - 100%)	25%
P14	Manual Standby Power - (5 - 100%)	10%
P15	Standby Temperature - (50° - 350° Fahrenheit), (50° - 175° Celsius)	250
P16	Soft Start Time - (0 - 20) minutes	5
P17	Soft Start Lock - (YES or NO)	YES
P18	Audible Alarm - (YES or NO)	YES
P19	Keypad Lock - (YES or NO)	NO
P20	Frequency (Hertz) DISPLAY ONLY	
P21	Tune Stabilization - (50 - 100)	60

GITC Parameters

#	Parameters	Defaults
P01	Group - (1 - 4)	1
P02	TRIAC Shorted Time (0-20)	10
P03	Even Temperature Rise - (YES or NO)	YES
P04	Thermocouple Slaving - (YES or NO)	YES
P05	Auto Power On - (YES or NO)	YES
P06	Control Type - Power Control Type Phase or Burst mode (PH or BT)	PH
P07	Over Current Limit - (1 - 21) Amps	16
P08	Celsius or Fahrenheit (°C or °F)	F
P09	Thermocouple Type - (J or K)	J
P10	Over-temp. Alarm Limit - (8° - 30° Fahrenheit), (6° - 17° Celsius)	30
P11	Under-temp. Alarm Limit - (5° - 30° Fahrenheit), (5° - 17° Celsius)	30
P12	T/C Pinched - (1 - 250) seconds or (000 = disabled)	60
P13	Open TRIAC, Heater - (1 - 240) seconds or (000 = disabled)	30
P14	APO Enable - (YES or NO)	YES
P15	Boost Time Setting - (5 - 999) seconds	30
P16	Boost Temp. - (5° - 250° Fahrenheit), (5° - 120° Celsius)	75
P17	Manual Boost Power - (5 - 100%)	25
P18	Manual Standby Power - (5 - 100%)	10
P19	Standby Temp. - (50° - 350° Fahrenheit), (50° - 175° Celsius)	250
P20	Soft Start Time - (0 - 20) minutes	5
P21	Soft Start Lock - (YES or NO)	YES
P22	Audible Alarm - (YES or NO)	YES
P23	Siren Enable LOCAL (per module) - (YES or NO)	YES
P24	Siren Enable GLOBAL - (YES or NO)	YES
P25	Address - DISPLAY ONLY	
P26	Tune Stabilization - (50 - 100)	60
P27	Keypad Lock - (YES or NO)	NO

Parameter Description

SITC-15	GITC-15	Description
	P01	Group - Set controller for specified group 1 - 4.
	P02	TRIAC Shorted Time - Time, in seconds, the controller will take to detect a TRIAC Shorted error.
	P03	Even Temperature Rise - Controllers follow slowest rising temperature in the system.
	P04	Thermocouple Slaving at Startup - At startup, in the even of a thermocouple break and controllers are below 140°F, the controller will slave from a controller in the same group.
P01	P05	Auto Power On - After a power outage, controller will automatically power up upon the return of power if enabled.
P02	P06	Control Type - Power output type (PH or BT) PH - half cycle phase mode BT - burst cycle mode
P03	P07	Over Current Limit Detection - Maximum amperage controller will allow for load (Over Current Condition (HIA)). Recommended for user to adjust to heater current +10% for better protection.
P04	P08	Select degrees Celsius (°C) or Fahrenheit (°F).
P05	P09	T/C Type - Select thermocouple types J or K.
P06	P10	Over-temp. Alarm Limit - Alarm when process temperature is over setpoint value as set in parameter.
P07	P11	Under-temp. Alarm Limit - Alarm when process temp. is under the setpoint value as set in parameter.
P08	P12	T/C Pinched - Time, in seconds, that the controller will take to detect a pinched or shorted thermocouple. (There is current, no rise in temperature).
P09	P13	Open TRIAC/Heater - Time, in seconds, that the controller will take to detect an open TRIAC, open heater, or open wire. (No current and no rise in temperature).
P10	P14	APO Enable - In the event of a T/C break and the controller is at set point, the controller uses the last average output power (APO) to maintain temperature. (Automatic Bumpless Transfer). T/C must be repaired as soon as possible.
P11	P15	Boost Time Setting - Time, in seconds, desired for boost mode.

Parameter Description (c)

SITC-15	GITC-15	Description
P12	P16	Auto Mode Boost Temp. - Boost temperature over setpoint. (Boost temp. + setpoint)
P13	P17	Manual Mode Boost Power - Manual percentage power output during boost mode for a set time (P15).
P14	P18	Manual Mode Standby Power - Manual percentage power output during standby mode.
P15	P19	Auto Mode Standby temp. - Standby/idle setpoint value.
P16	P20	Soft-Start Time - Time duration, in minutes, that the controller is in Soft-Start. (Bake Out)
P17	P21	Soft-Start Lock - Prevents users from changing mode while in soft-start.
P18	P22	Audible Alarm Enable/Disable - controller audible alarm.
	P23	Local Siren Enable/Disable - siren alarm for the individual controller.
	P24	Global Siren Enable/Disable - siren alarm global.
	P25	Zone Address - Controller zone location in mainframe (Display only).
P20		Frequency - AC line frequency (Display only).
P21	P26	Tuning Stabilization - Adjustment for heaters with lagging thermocouple or low mass (quick heat dissipation heaters). If there is fluctuation of temperature, adjust higher (recommended maximum of 75).
P19	P27	Keypad Lock - YES: Disables all keys, except for the *PMTR* key, to prevent unwanted changes. NO: All keys enabled.

Display Codes

Display Codes: Displayed on PRT (process temperature display)

Display Code	Description	Explanation
Hi	High Temperature	Process temp. over setpoint value.
Lo	Low Temperature	Process temp. under setpoint value.
OTC	Open Thermocouple	Thermocouple is open or break.
RTC	Reverse Thermo- couple	Thermocouple wire reversed.
PTC	Pinched Thermo- couple	Thermocouple has been shorted/ pinched.
TOH	Open TRIAC/Heater	TRIAC, heater is open.
TSH	TRIAC/Heater Shorted	TRIAC or heater shorted. (100% power output)
HIA	Over Current Detec- tion	Load has exceeded the amperage set in parameters.
APO	Average Power Output	Thermocouple is open and APO is currently running.
GLO	Global Function	Global key has been pressed. (GITC only)

NOTE: Power off controller before removing or inserting into mainframe




Figure 3

Pin 1 & 2 - For newer style mainframes with anti-arcing protection.

Pin 2 & 3 - For older style mainframes without anti-arcing protection.

Anti-Arcing Protection: Jumper J7 is to prevent damage to the contact points of the controller when removed from the mainframe while power is still on. J7 is set to pins 1 & 2 by factory default. If the controller is placed in an older mainframe without anti-arcing protection, place jumper on pins 2 & 3. If jumper is placed incorrectly, a TOH error may occur (NO POWER OUPUT).

Mainframe Installation

INSTALLATION AND SERVICE SHOULD BE PERFORMED BY QUALIFIED PERSONNEL ONLY!

LOCATION:

The proper location is important for dependable service. The control systems should be located so as to allow free air movement into and out of the mainframe. Consideration should be given to allow the least exposure to heat, dust/dirt, moisture, and corrosive vapors. The front of the system must be readily accessible for set up and adjustment purposes.

It is recommended that a service disconnect switch be installed. This will provide a convenient means to completely disconnect all power from the temperature control system.

CONNECTING INPUT POWER:

1. Remove the input power access panel, located on the right side of the mainframe by removing the 8 phillips head screws. (Fig 4a)
2. Select input cable size and configuration based on load requirements and local electrical codes. Feed the cable through the cable clamp of the panel. (Fig 4b)
4. Strip wires and insert into the terminal block and tighten screws securely. (Fig 4a)
5. Replace the access panel.
6. Take up excess slack in the cable and secure with the strain relief clamp.
7. Route the AC input cable to a branch circuit (service) disconnect switch and connect to the fused side of the switch. Be sure the ground lead is attached to a proper earth ground.
8. Insert appropriate fuses for the main service fuse box.

Mainframe Input Power Diagram




Figure 4a




Figure 4b

Note:

Domestic: L1, L2, L3 + ground

Export: L1, L2, L3 + Neu + ground

Single Phase: L1 + Neu + ground

Mainframe Interconnection to Mold Terminal Box

Figure 5





Figure 6a


Power Connector Pinout



Pin	Zone	Pin	Zone	Pin	Zone
A1	Zone 1			C1	Zone 8
A2		B2	Zone 5	C2	
A3	Zone 2	B3			C3
A4		B4	Zone 6	C4	
A5	Zone 3	B5			C5
A6		B6	Zone 7	C6	
A7	Zone 4	B7			C7
A8		B8		C8	
A9	Zone 12			C9	Zone 12

Figure 6b

T/C Connector Pinout



MFCP Mainframe (GITC ONLY)



MFCP mainframes come with communication and interface board with siren, which enables global functions, grouping, thermocouple slaving, even temperature rise, and Live Swap features. External alarm relay, and remote standby interface connector is located on the right side above the power input panel. Figures 7, a, and b below shows connector and external wiring circuits needed for these functions.

Alarm/Relay Output & Remote Standby Input Connector




Figure 7

Pin #	Function
1	Remote Standby Input
2	
3	Alarm/Relay Output
4	




1 & 2 Zone Mainframe Power and Thermocouple Connector

Figure 8



Pin #	Function
1	Power Output
2	T/C +
3	T/C -
4	Power Output
5	GND

3 Zone Mainframe Power and Thermocouple Connector



Pin #	Function	Pin#
1	Zone 1 Power Out	9
2	Zone 2 Power Out	10
3	Zone 3 Power Out	11
4	NC	12
5	NC	13
6	Zone 1 T/C Input	14
7	Zone 2 T/C Input	15
8	Zone 3 T/C Input	16

Figure 9

Note:

1, 2, and 3 zone mainframes are wired for single phase 240VAC operation.

Warranty

This product is guaranteed to be free from defects in materials and workmanship for a period of two years from the date of delivery. If the unit should malfunction, it must be returned to the factory for evaluation. Upon examination, if the unit is found to be defective, at our option, it will be repaired or replaced at no cost to the customer.

Warranty does not cover: contact points, fuses, or triacs.

Warranty is null and void when: Signs of abuse or tampering are found, incorrect fuse type is used, application of High Voltage rated over the system's required specifications, or application of High Voltage to thermocouple inputs.

MCS accepts no responsibility or liability for the APPLICATION by the customer of temperature controllers. This liability is assumed by the customer. Upon inspection, if the returned product does not meet our warranty requirements, customer may be subject to a reasonable service charge. There are no warranties, expressed or implied, for temperature controllers except as stated herein. In no event shall MCS be liable for consequential, incidental, or special damages beyond our control. The buyer's sole remedy for any breach of this agreement shall not exceed the purchase price paid by the buyer to MCS.

Manufactured by:

Mold Control Systems, Inc.

10501 S. Orange Ave. STE #108

Orlando, FL 32824

PH: 407-855-2899

FAX: 407-855-2855